

EUROPEAN SPALLATION SOURCE

Luminescent Materials Development for Beam-on-Target Imaging at the European Spallation Source

Thomas Shea (Presenter, European Spallation Source ERIC)

C. Thomas, J. Habainy, M. Hartl, Y. Lee (European Spallation Source ERIC) E. Adli, H. Gjersdal, M. Jaekel, D. Wragg (University of Oslo) S. Joshi, S. Bjorklund (University West) S. Sampath (Stony Brook University) W. Blokland (Oak Ridge National Laboratory)

IWSMT, Chattanooga 2016-11

ESS Beam-on-Target Imaging



EUROPEAN SPALLATION SOURCE

0

× [mm]



Luminescent Coating Development Goals

- **High photon yield:** Require adequate signal relative to background and noise. Example: 250 photons per proton (similar to SNS) results in 1e10 photons per pulse through optics and onto image sensor.
- Appropriate emission spectrum: Within range where imaging sensors are efficient (visible and nearby IR and UV bands), and selectable from He background.

EUROPEAN SPALLATION

- Short luminescence lifetime: Time between pulses ~70 ms. Target wheel moves 8 mm during pulse. Rastered beamlet scans at ~10 mm/μs.
- **High radiation tolerance:** 8.75E20 p/cm^2 lifetime proton fluence per sector, with most displacement damage due to spallation neutrons
- Characterized (and moderate) temperature dependence: Temperature up to ~200 C peak, with ~20 C increase during pulse. Non-uniform temperature distribution.
- Characterized response to secondary particles: Secondaries will also stimulate emission and distort image.
- **Compatibility with thermal spray process**. Sprayable without degrading properties of 316L or Al substrate.
- Tolerance of gas environment: Helium impurities or ~mbar vacuum pressure.

Also relevant for other ESS imaging applications: beam window and tuning dump ³

Downselection Process



- Material selection and evaluation of process compatibility
- Sample preparation: process refinement; factory floor testing
- Photoluminescence and low energy particle beams

Result at this stage: candidates for irradiation campaigns

- Irradiation with no or minimal activation*
- Irradiation with significant activation*
- Industrialization

Result: coating technology for target

- * Pre- and Post-irradiation characterization
 - photon and proton stimulation
 - X-ray and neutron scattering

Candidate Materials



- Materials:
 - Baseline: Cr3+ doped Al2O3; developed for SNS; ruby; also shows O2 lines
 - Y2O3: radiation hard, broad luminescence signal
 - > Can be doped to enhance some specific narrow band lines
 - Y₂WO₆ and doped Ln_xY_{2-x}WO₆ (Ln=La³⁺, Dy³⁺, ...): according to literature will form easily O2 in defect positions, luminescence sharp and short-lived for certain doped materials.
 - Still adding to the list based on key criteria
- Luminescence properties:
 - High luminescent yield: greater than 250 photons/2GeV proton
 - Narrow band spectral lines: less than 10nm
 - Lifetime shorter than 1µs lifetime
- Radiation hardness:
 - material should survive in a high-radiation field for 5 years
 - material should when degrading provide alternate source of luminescence, e.g. "O₂" in defect positions



EUROPEAN SPALLATION SOURCE

Activities

Sample Preparation



- Continuation thermal spray coating development done by Stony Brook University for SNS
- Short-term Goal: Spray deposition, testing of Al₂O₃-1.5 wt.% Cr₂O₃ coatings to replicate the SNS results.
- Previously used powder no longer in stock, so develop coating with currently available powder





EUROPEAN SPALLATION

SOURCE

Thermal spray gun

 Looking ahead: Other promising chemistries being explored (e.g., Y2O3, YVO4, Y2WO6 with and without doping); these can be deposited by powder / suspension / solution-precursor plasma spraying

Photostimulated Luminescence



EUROPEAN SPALLATION SOURCE





Factory floor inspection kit



Comparison to SNS emission spectrum



Low-energy proton beam

- SCANDITRONIX MC-35 Cyclotron at University of Oslo
- 16 MeV, 2-3µA, 1-2cm² beam size, continuous beam
- Semi-permanent setup, new materials can be tested quickly





Broad Yttria spectrum





Temperature Dependence



EUROPEAN SPALLATION SOURCE

10



- 18 to 175 C: R-lines lose amplitude with temperature
- Emission below the R-line increases with temperature
- Could also be a temperature diagnostic if characterized over irradiation lifetime



High Energy Protons



EUROPEAN SPALLATION SOURCE



- High intensity, high energy proton beam from CERN SPS
- 10¹¹ 440 GeV protons per pulse
- Limited access. A few hundred pulses once a year.
- Results to be published



Yttrium stabilized Zirconia in HiRadMat beam. GSI irradiated (left), non-irradiated (right).





SNS in-situ Measurements



High energy proton beam, target radiation environment most similar to ESS

Example measurements:

- Luminescence yield vs. dose
- Time resolved imaging
- Emission spectrum
 - In addition to R-lines from the Cr3+ doped Al2O3 and He lines: emission at 777nm and 426nm, <1µs lifetime, almost constant intensity after initial irradiation
 - Ruby and He lines imaged; O2 lines not yet successfully imaged



Luminescent intensity vs. time (s)



Heavy Ion Bombardment

EUROPEAN SPALLATION SOURCE

- Radiation tolerance investigation with limited activation
- Example: Al₂O₃:Cr under (GSI) U²³⁸ Irradiation:
 - 4.8 MeV/nucleon U (26e⁺), 1.0e10 U/cm²
 - Accumulated total fluence: 10^12 U/cm2.
 - 1.8x10-3 DPA at 20 μm : 1 day at 5 MW ESS
 - 1.8*10-5 dpa at 1 μm







X-ray Diffraction



EUROPEAN SPALLATION SOURCE

After irradiation @ GSI

- No uranium detectable
- decrease of η -Al₂O₃
- Aluminium reflections detected:

Al₂O₃ -> 2Al + 3/2 O₂

Explanation for O₂ peaks in luminescence spectrum from SNS target?!



Additional X-ray and Neutron Characterization Techniques



EUROPEAN SPALLATION SOURCE

- XANES: oxidation state and surrounding of dopants in bulk materials, e.g. Cr³⁺ in Al₂O₃ or La³⁺ in Y₂WO₆
- Diffraction with X-rays and neutrons:
 - to determine structure and phase changes (powder diffraction)
 - to determine macroscopic structure (small angle diffraction)



- XAFS at MAX-II for SNS Cr^{3+} doped Al_2O_3 :
 - As expected: Cr³⁺
 - Cr³⁺ is in octahedral surrounding (Al₂O₃ consists of Al(O)4 tetraehedra)

✓ Tools in place for the determination of the structure and composition

Irradiation Campaigns with Significant Activation



EUROPEAN SPALLATION SOURCE

- BLIP, 2017
 - Sample list:
 - Al2O3:Cr (1% Cr) several plasma spray conditions
 - Y2O3 plasma sprayed
 - Y2WO6 pellet
 - 181 MeV, 165 uA
 - Temperature < 144 C</p>
 - 0.85 DPA in Al after 12 weeks
- SNS target sample retrieval
 - Coating sample area in corners
 - Retrieve coating samples for PIE





- 3 mm diameter samples
- \sim 50 µm coating on 0.5 mm Al

Outlook



- Coming year
 - Decision on coating technology for 1st target coating opportunity: rim components in 2017.
 - BLIP/SNS/Ion irradiation and PIE
 - Identification of proton beam test site, neutron and X-ray instruments, and other PIE facilities
 - Monte Carlo and experimental verification of response to secondaries
- R&D program will continue
 - 2nd target coating opportunity: completed assembly in 2018.
 - Application to proton beam window, tuning dump line, next ESS target, SNS target and other facilities



EUROPEAN SPALLATION SOURCE

Thank you